



Mounting instructions for shelter closures

- standardized shuttering device 1 for shelter closures, also shuttering boards can be used.
- door body and frame have to be placed vertically and accurately wedged to the wall shuttering boards 2. Door and frame must not be separated.
- the wall has to be cast first, only once the concrete has set enough the door can be cast, in closed position.
- between top edge of door body and finished ceiling and bottom edge of door body and finished floor the minimum clearance has to be 4 cm.
- while casting and painting the rubber seal must not be removed.

Modifications reserved